

02.06.2023

# **MISCELLANEOUS RUBBER-TIRED** & TRACKED EQUIPMENT

KEEP ON TRACKIN' - THE RIGHT WAY.

The Company's owns, operates, and maintains a vast equipment fleet. Most of the fleet has equipment specific policies in this safety manual. The policies and procedures that follow apply to miscellaneous rubber-tired and tracked equipment units for which a specific Company policy is not provided.

99

## REMEMBER

THE CARE AND JUDGMENT YOU USE WHILE OPERATING YOUR MACHINE DETERMINE YOUR SAFETY, AND THE SAFETY OF THOSE AROUND YOU.

#### **BEFORE STARTING**

- Inspect the entire machine to be sure it is in good operating condition.
- Check tires/tracks (if applicable) for excessive wear and proper inflation.
- Check all fluid levels.
- Never operate a machine which is new to you without first being instructed in its proper operations.
- Never start a machine if there is a warning tag on the starting switch or engine starting controls.
- Never attempt to start engine except from operator's station.
- Never attempt to operate the controls except from the operator's station.
- Be sure the work area is safe.

### START-UP

- Always use seatbelts if your machine is equipped with a Roll-Over-Protection-Structure.
- Know proper starting procedure.
- Check all gauges for proper readings.
- Check operation of service and parking brake.
- Use 3 points of contact to mount and dismount equipment.

## **OPERATIONS**

- Never mount or dismount a machine that is moving.
- Constantly check your work area for potential hazards.
- Do not operate the machine if the controls malfunction.
- Never allow unqualified or unauthorized personnel to ride on the machine. Never enter or place any part of your body in the hinge area or
- other pinch areas of an articulated machine while the engine is running, or when there is any chance another person might start the engine.
- Never abuse your machine. Misuse or abuse can cause an accident.
- Never speed and never coast in neutral.
- Always look in all directions before reversing your direction of travel.

the engine is shut off.

SHUT DOWN

• Park on level ground whenever possible. When not possible,

- position the machine at right angles to the slope. Know the proper shut-down procedure for your machine. Follow
- the manufacturers operation manual for your machine. Remove the key(s) to prevent unauthorized starting and
- movement, and position and lock and anti-vandalism devices. Never dismount from your machine until it is fully stopped, and